

## BPS EQUIPMENT HEATER & SPARES LIST

<u>Image</u>	<u>Part Number</u>	<u>Description</u>
	6601-9050 6601-9051	Hired Hand Super Saver Heater LPG Hired Hand Super Saver Heater NG
	6450-0220	OSM KIT FOR HH-SS-225XL-UM-G
	6401-2877	Locked Air Deflector
	3001-1740	Sail Switch
	3005-0107	Thermostat Disc
	3005-0108	Thermostat Disc (D.S.I)
	3002-5001	Ignitor (Hot Surface)
	3002-6010	Ignitor (D.S.I)
	6450-0091 6450-0093	Flame Probe Long Flame Probe Short
	3003-3004	Flame Probe (D.S.I)
	3005-2130	Thermostat T-19 (Wash Down Resistant)
	BPS-4403-B46	B46 LPG Regulator
	6401-5033	Transformer 40 va CE (Right Hand Side)
	6401-5032	Transformer 40 va CE (Left Hand Side)

	3008-2259	Transformer CFTCP40 (D.S.I)
	6401-5031	Hot Surface Control Plate
	6401-1147	Older Style UT Control Plate
	6401-5074	Control Plate (D.S.I)
	3591-2258	Hot Surface Pektron Module
	3591-0100	Older Style UT Module
	3591-2264	Module (D.S.I)
	6401-5036	Blower Wheel Assembly
	6401-1318	Blower Wheel
	3017-5090	Blower Motor 1/3 hp 230v
	0409-3002	Orifice
	6401-5049 6401-5050	Honeywell Gas Valve Assembly Natural Gas Valve Assembly
	6401-1309	Burner Plate
	BPS-OH-001	Orange 1/2"NB LPG Hose 3MTR 1/2"M by 3/4"F
	3504-5008	Motor Capacitor
	3010-2293	Fuse 2 Amp 1/4 x 1-1/4 (DSI)
	3010-2294	Fuse 1/4 AMP 1/4 x 1-1/4 (DSI)
	0408-1131	Blower Motor Mount Plate
	0408-6673	DSI Blower Motor Mount Plate